

Connection Diagram

FCB-IX Sesies



FCR-FX Series



* Described in the reference circuit diagram in the technical manual.